



Alesis Palmtrack V3.1 Teardown

Opening and disassembling of the Alesis Palmtrack V3.1

Written By: Lorca Strand



Step 1 — Alesis Palmtrack V3.1 Teardown




- Open the back battery cover

Step 2




- Unscrew the four back screws

Step 3




- Remove the backing and the wire mesh microphone casing.
- NOTE: The Speaker is connected to the motherboard and adhered to the back cover, so take caution when opening. I cannot foretell the chaos created if you break the speaker wire.

Step 4




- Gently pull apart main plate from front cover.
- Also note that there is a ribbon cable connecting the front circuit board to the motherboard

Step 5



- Disconnect the ribbon cable.

Step 6



- Feed the ribbon cable through this opening. This is much easier than disconnecting from the front circuit board, which requires delicate, if not impossible maneuvers to reconnect upon reassembly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 12:40:38 PM.